

SimFlame Lamp Flicker Module

visit – www.simflame.com for additional information

LM015 Single Channel

General Instructions:

Set desired effect using DIP switches located on underside of module, plug lamp into Simflame module, plug Simflame module into wall outlet and enjoy.

DO NOT exceed 100 watts total lamp load.
USE ONLY incandescent or halogen lamps.
Operates on 120V 60 hertz.

DIP Switch Settings:

Switch #1 – depth of flicker.

- a) down = subtle flicker, best candle effect.
- b) up = lamps dim deeper.

Switch #2 – speed of flicker.

- a) down = slow, best candle effect.
- b) up = fast.

Switch #3 – intensity.

- a) down = dim mode, best candle effect.
- b) up = bright mode.

Disclaimer and Warranty

Jerry's Electronics warrants all Simflame™ products to be free of functional defects, assuming proper application and normal use, for a period of one (1) year from date of purchase. The company will correct such defects by repair or replacement, at its option, if product is returned prepaid with proof of original purchase date. Please note that defects resulting from miswire, short circuit or output overload may be verified by factory tests and are specifically excluded from warranty.

Except for the express warranty set forth above, Jerry's Electronics grants no other warranties, express or implied, by statute or otherwise, regarding Simflame products, their merchantability, fitness for any particular purpose or otherwise. In no event shall Jerry's Electronics or any agent or reseller be liable for any other loss or damage, including special or consequential damages that may arise through the use by a purchaser or others, and the purchaser assumes and will hold Jerry's Electronics harmless in respect of all such loss.